

Anime and Computers Direct, Ltd.

Battery List

E-mail us at battery@animeandcomputers.com if you would like a price on any of the batteries or accessories listed.

Laptop Batteries & Adapters

Laptop Batteries & Adapters

Apple

iBook (1999 model - original) B-5898 B-5755L / B-5760L AC-D55 DK-D55 -
iBook (2000 model - original) B-5898 B-5755L / B-5760L AC-D55 DK-D55 -
iBook (Blueberry) B-5898 B-5755L / B-5760L AC-D55 DK-D55 -
iBook (Dual USB - 12") B-5901 B-5755M / B-5760M AC-D56 DK-D56 -
iBook (Dual USB - 14") - B-5755M / B-5760M AC-D56 DK-D56 -
iBook (Graphite) B-5898 B-5755L / B-5760L AC-D55 DK-D55 -
iBook (Indigo) B-5898 B-5755L / B-5760L AC-D55 DK-D55 -
iBook (Lime Green) B-5898 B-5755L / B-5760L AC-D55 DK-D55 -
iBook (Tangerine) B-5898 B-5755L / B-5760L AC-D55 DK-D55 -
iBook (White - 12") B-5901 B-5755M / B-5760M AC-D56 DK-D56 -
iBook (White - 14") - B-5755M / B-5760M AC-D56 DK-D56 -
PowerBook G3 (bronze keyboard) B-5899 B-5755L / B-5760L AC-D55 DK-D55 -
PowerBook G3 (FireWire) B-5899 B-5755L / B-5760L AC-D55 DK-D55 -
PowerBook G3 1998 B-5896 B-5755L / B-5760L AC-D55 DK-D55 -
PowerBook G3 1999 B-5899 B-5755L / B-5760L AC-D55 DK-D55 -
PowerBook G3 Lombard B-5899 B-5755L / B-5760L AC-D55 DK-D55 -
PowerBook G3 Pismo B-5899 B-5755L / B-5760L AC-D55 DK-D55 -
PowerBook G3 Wall Street B-5896 B-5755L / B-5760L AC-D55 DK-D55 -
PowerBook G4 Titanium B-5902 B-5755M / B-5760M AC-D56 DK-D56 -

Compaq

Armada 1500 series B-5514/LI - - - -
Armada 7300 series B-5502 - - - -
Armada 7400 series B-5503 - - - -
Armada 7700 series B-5515 - - - -
Armada 7800 series B-5516 - - - -
Armada E500 B-5521 B-5755F / B-5760F AC-C14 DK-C14 AA-C14
Armada E500s B-5521 B-5755F / B-5760F AC-C14 DK-C14 AA-C14
Armada E700 - B-5755F / B-5760F AC-C14 DK-C14 AA-C14
Armada M300 - B-5755F / B-5760F AC-C14 DK-C14 AA-C14
Armada M700 B-5520 B-5755F / B-5760F AC-C14 DK-C14 AA-C14
Armada V300 B-5521 B-5755F / B-5760F AC-C14 DK-C14 AA-C14
Evo N1000 series B-5538 - AC-C16 - -
Evo N105 B-5533LI B-5755A / B-5760A AC-C10 DK-C10 AA-C10
Evo N110 - B-5755F / B-5760F AC-C14 DK-C14 AA-C14
Evo N115 B-5533LI B-5755A / B-5760A AC-C10 DK-C10 AA-C10
Evo N150 - B-5755F / B-5760F AC-C14 DK-C14 AA-C14
Evo N160 B-5522 B-5755A / B-5760A AC-C10 DK-C10 AA-C10
Evo N180 B-5528 B-5755A / B-5760A AC-C10 DK-C10 AA-C10
Evo N200 B-5527 B-5755F / B-5760F AC-C14 DK-C14 AA-C14
Evo N400c - B-5755F / B-5760F AC-C14 DK-C14 AA-C14
Evo N410c - B-5755F / B-5760F AC-C14 DK-C14 AA-C14
Evo N600c - B-5755F / B-5760F AC-C14 DK-C14 AA-C14
Evo N610c - B-5755F / B-5760F AC-C14 DK-C14 AA-C14

Laptop Batteries & Adapters

Laptop Batteries & Adapters

4

Compaq (cont.)

Evo N800 series B-5538 B-5755F / B-5760F AC-C14 DK-C14 AA-C14
Presario 1200 series B-5505, B-5505/LI B-5755A / B-5760A AC-C10 DK-C10 AA-C10
Presario 12XL series B-5505, B-5505/LI B-5755A / B-5760A AC-C10 DK-C10 AA-C10
Presario 1400 series B-5523, B-5523LI B-5755A / B-5760A AC-C10 DK-C10 AA-C10
Presario 14XL series B-5523, B-5523LI B-5755A / B-5760A AC-C10 DK-C10 AA-C10
Presario 1600 series B-5505, B-5505/LI B-5755A / B-5760A AC-C10 DK-C10 AA-C10
Presario 1700 series B-5522 B-5755A / B-5760A AC-C10 DK-C10 AA-C10
Presario 17XL series B-5522 B-5755A / B-5760A AC-C10 DK-C10 AA-C10
Presario 1800 series B-5505, B-5505/LI B-5755A / B-5760A AC-C10 DK-C10 AA-C10
Presario 18XL series B-5505, B-5505/LI B-5755A / B-5760A AC-C10 DK-C10 AA-C10
Presario 1900 series B-5517 - AC-D57 DK-D57 -
Presario 2700 series B-5528 B-5755A / B-5760A AC-C10 DK-C10 AA-C10
Presario 2800 series B-5538 B-5755F / B-5760F AC-C14 DK-C14 AA-C14
Presario 700 series B-5533LI B-5755A / B-5760A AC-C10 DK-C10 AA-C10
Presario 800 series B-5530 B-5755A / B-5760A AC-C10 DK-C10 AA-C10
Presario 900 series B-5538 B-5755F / B-5760F AC-C16 - -
Prosignia 150 B-5505, B-5505/LI B-5755A / B-5760A AC-C10 DK-C10 AA-C10
Prosignia 170 B-5520 B-5755F / B-5760F AC-C14 DK-C14 AA-C14

Dell

Inspiron 3700 B-5630 B-5755E / B-5760E AC-C50/L DK-C50/L AA-C50L
Inspiron 3800 B-5630 B-5755E / B-5760E AC-C50/L DK-C50/L AA-C50L
Inspiron 4000 B-5630 B-5755E / B-5760E AC-C50/L DK-C50/L AA-C50L
Inspiron 5000 series B-5636 B-5755E / B-5760E AC-C50/L DK-C50/L AA-C50L
Inspiron 7000 series B-5666 B-5755A / B-5760A AC-C10 DK-C10 AA-C10
Inspiron 7500 series B-5666 B-5755E / B-5760E AC-C50/L DK-C50/L AA-C50L
Inspiron 8000 B-5630 B-5755E / B-5760E AC-C50/L DK-C50/L AA-C50L
Inspiron 8100 B-5630 B-5755E / B-5760E AC-C50/L DK-C50/L AA-C50L
Inspiron 8200 B-5630 - AC-C50LH - -
Latitude C500 B-5630 B-5755E / B-5760E AC-C50/L DK-C50/L AA-C50L
Latitude C510 B-5630 B-5755E / B-5760E AC-C50/L DK-C50/L AA-C50L
Latitude C600 B-5630 B-5755E / B-5760E AC-C50/L DK-C50/L AA-C50L
Latitude C610 B-5630 B-5755E / B-5760E AC-C50/L DK-C50/L AA-C50L
Latitude C640 B-5630 - - - -
Latitude C800 B-5630 B-5755E / B-5760E AC-C50/L DK-C50/L AA-C50L
Latitude C810 B-5630 B-5755E / B-5760E AC-C50/L DK-C50/L AA-C50L
Latitude C840 B-5630 - AC-C50LH - -
Latitude CP series B-5630 B-5755E / B-5760E AC-C50/L DK-C50/L AA-C50L
Latitude XP series B-5632 B-5755D / B-5760D AC-C25 DK-C25 AA-C25
Latitude XPI series B-5632 B-5755E / B-5760E AC-C50/L DK-C50/L AA-C50L

Laptop Batteries & Adapters

Laptop Batteries & Adapters

5

Gateway

Solo 2300 series B-5787T B-5755C / B-5760C AC-C15 DK-C15 AA-C15
Solo 2500 series B-5787T B-5755C / B-5760C AC-C15 DK-C15 AA-C15
Solo 5300 series B-5788 - - - -
Solo 9100 series B-5787 B-5755C / B-5760C AC-C15 DK-C15 AA-C15

Hewlett Packard

OmniBook XE B-5648 B-5755A / B-5760A AC-C10 DK-C10 AA-C10
OmniBook XE2 B-5648 B-5755A / B-5760A AC-C10 DK-C10 AA-C10
OmniBook XE3 B-5640, B-5640LI B-5755A / B-5760A AC-C10 DK-C10 AA-C10
Pavilion N3000 series B-5648 B-5755A / B-5760A AC-C10 DK-C10 AA-C10
Pavilion N3400 series B-5648 B-5755A / B-5760A AC-C10 DK-C10 AA-C10
Pavilion N5100 series B-5640, B-5640LI B-5755A / B-5760A AC-C10 DK-C10 AA-C10
Pavilion N5200 series B-5640, B-5640LI B-5755A / B-5760A AC-C10 DK-C10 AA-C10
Pavilion N5300 series B-5640, B-5640LI B-5755A / B-5760A AC-C10 DK-C10 AA-C10

Pavilion N5400 series B-5640, B-5640LI B-5755A / B-5760A AC-C10 DK-C10 AA-C10
Pavilion N5500 series B-5640, B-5640LI B-5755A / B-5760A AC-C10 DK-C10 AA-C10
Pavilion N6000 series B-5652 B-5755A / B-5760A AC-C10 DK-C10 AA-C10
Pavilion XF series - - AC-C10H - -
Pavilion XH series B-5640, B-5640LI B-5755A / B-5760A AC-C10 DK-C10 AA-C10
Pavilion XZ series B-5651 B-5755A / B-5760A AC-C10 DK-C10 AA-C10
Pavilion ZT series B-5651 - AC-C10H - -

IBM

ThinkPad 240 series B-5606, B-5608 B-5755K / B-5760K AC-B10 DK-B10 AA-B10
ThinkPad 380 B-5616, B-5616/LI B-5755K / B-5760K AC-B10 DK-B10 AA-B10
ThinkPad 380D B-5616, B-5616/LI B-5755K / B-5760K AC-B10 DK-B10 AA-B10
ThinkPad 380D-MMX B-5616, B-5616/LI B-5755K / B-5760K AC-B10 DK-B10 AA-B10
ThinkPad 380E B-5616, B-5616/LI B-5755K / B-5760K AC-B10 DK-B10 AA-B10
ThinkPad 380ED B-5616, B-5616/LI B-5755K / B-5760K AC-B10 DK-B10 AA-B10
ThinkPad 380XD B-5616, B-5616/LI B-5755K / B-5760K AC-B10 DK-B10 AA-B10
ThinkPad 380Z B-5616, B-5616/LI B-5755K / B-5760K AC-B10 DK-B10 AA-B10
ThinkPad 385 series B-5616, B-5616/LI B-5755K / B-5760K AC-B10 DK-B10 AA-B10
ThinkPad 390 series B-5618, B-5618LI B-5755K / B-5760K AC-B10 DK-B10 AA-B10
ThinkPad 570 series B-5602 B-5755K / B-5760K AC-B10 DK-B10 AA-B10
ThinkPad 600 series B-5614 B-5755K / B-5760K AC-B10 DK-B10 AA-B10
ThinkPad 760 series B-5624, B-5624/LI B-5755G / B-5760G AC-C40 DK-C40 AA-C40
ThinkPad 765 series B-5624, B-5624/LI B-5755G / B-5760G AC-C40 DK-C40 AA-C40
ThinkPad 770 series B-5626 B-5755K / B-5760K AC-B10 DK-B10 AA-B10
ThinkPad A20 series B-5603 B-5755K / B-5760K AC-B10 DK-B10 AA-B10
ThinkPad A30 series - B-5755K / B-5760K AC-B10 DK-B10 AA-B10
ThinkPad i 1200 B-5625, B-5625MH B-5755K / B-5760K AC-B10 DK-B10 AA-B10
ThinkPad i 1210 B-5625, B-5625MH B-5755K / B-5760K AC-B10 DK-B10 AA-B10

Laptop Batteries & Adapters

Laptop Batteries & Adapters

6

IBM (cont.)

ThinkPad i 1211 B-5629 B-5755K / B-5760K AC-B10 DK-B10 AA-B10
ThinkPad i 1241 B-5629 B-5755K / B-5760K AC-B10 DK-B10 AA-B10
ThinkPad i 1251 B-5629 B-5755K / B-5760K AC-B10 DK-B10 AA-B10
ThinkPad i 1271 B-5629 B-5755K / B-5760K AC-B10 DK-B10 AA-B10
ThinkPad i 1300 series B-5629 B-5755K / B-5760K AC-B10 DK-B10 AA-B10
ThinkPad i 1400 B-5627 B-5755C / B-5760C AC-C15 DK-C15 AA-C15
ThinkPad i 1410 B-5627 B-5755C / B-5760C AC-C15 DK-C15 AA-C15
ThinkPad i 1411 B-5627 B-5755C / B-5760C AC-C15 DK-C15 AA-C15
ThinkPad i 1412 B-5629 B-5755C / B-5760C AC-C15 DK-C15 AA-C15
ThinkPad i 1416 B-5627 B-5755C / B-5760C AC-C15 DK-C15 AA-C15
ThinkPad i 1417 B-5627 B-5755C / B-5760C AC-C15 DK-C15 AA-C15
ThinkPad i 1418 B-5628, B-5628MH B-5755K / B-5760K AC-B10 DK-B10 AA-B10
ThinkPad i 1420 B-5628, B-5628MH B-5755K / B-5760K AC-B10 DK-B10 AA-B10
ThinkPad i 1421 B-5628, B-5628MH B-5755K / B-5760K AC-B10 DK-B10 AA-B10
ThinkPad i 1434 B-5627 B-5755C / B-5760C AC-C15 DK-C15 AA-C15
ThinkPad i 1435 B-5627 B-5755C / B-5760C AC-C15 DK-C15 AA-C15
ThinkPad i 1436 B-5627 B-5755C / B-5760C AC-C15 DK-C15 AA-C15
ThinkPad i 1441 B-5628, B-5628MH B-5755K / B-5760K AC-B10 DK-B10 AA-B10
ThinkPad i 1442 B-5628, B-5628MH B-5755K / B-5760K AC-B10 DK-B10 AA-B10
ThinkPad i 1450 B-5627 B-5755C / B-5760C AC-C15 DK-C15 AA-C15
ThinkPad i 1451 B-5627 B-5755C / B-5760C AC-C15 DK-C15 AA-C15
ThinkPad i 1452 B-5629 B-5755C / B-5760C AC-C15 DK-C15 AA-C15
ThinkPad i 1454 B-5627 B-5755C / B-5760C AC-C15 DK-C15 AA-C15
ThinkPad i 1460 B-5628, B-5628MH B-5755K / B-5760K AC-B10 DK-B10 AA-B10
ThinkPad i 1470 B-5629 B-5755C / B-5760C AC-C15 DK-C15 AA-C15
ThinkPad i 1472 B-5629 B-5755C / B-5760C AC-C15 DK-C15 AA-C15
ThinkPad i 1476 B-5629 B-5755C / B-5760C AC-C15 DK-C15 AA-C15
ThinkPad i 1480 B-5628, B-5628MH B-5755K / B-5760K AC-B10 DK-B10 AA-B10
ThinkPad i 1482 B-5628, B-5628MH B-5755K / B-5760K AC-B10 DK-B10 AA-B10
ThinkPad i 1500 B-5628, B-5628MH B-5755K / B-5760K AC-B10 DK-B10 AA-B10
ThinkPad i 1512 B-5629 B-5755C / B-5760C AC-C15 DK-C15 AA-C15
ThinkPad i 1542 B-5629 B-5755C / B-5760C AC-C15 DK-C15 AA-C15
ThinkPad i 1552 B-5629 B-5755C / B-5760C AC-C15 DK-C15 AA-C15
ThinkPad i 1560 B-5629 B-5755C / B-5760C AC-C15 DK-C15 AA-C15

ThinkPad i 1720 B-5618, B-5618LI B-5755K / B-5760K AC-B10 DK-B10 AA-B10
ThinkPad i 1721 B-5618, B-5618LI B-5755K / B-5760K AC-B10 DK-B10 AA-B10
ThinkPad R30 B-5653 B-5755K / B-5760K AC-B10 DK-B10 AA-B10
ThinkPad R31 B-5653 B-5755K / B-5760K AC-B10 DK-B10 AA-B10
ThinkPad R32 - B-5755K / B-5760K AC-B10 DK-B10 AA-B10
ThinkPad T20 series B-5601 B-5755K / B-5760K AC-B10 DK-B10 AA-B10
ThinkPad T30 - B-5755K / B-5760K AC-B10 DK-B10 AA-B10
ThinkPad X20 series B-5605 B-5755K / B-5760K AC-B10 DK-B10 AA-B10

Laptop Batteries & Adapters

Laptop Batteries & Adapters

7

Micron

Transport GX B-5887LIS B-5755N / B-5760N AC-C26 DK-C26 AA-C26
TransPort GX+ B-5887LIS B-5755N / B-5760N AC-C26 DK-C26 AA-C26
TransPort GX2 B-5887LIS B-5755N / B-5760N AC-C26 DK-C26 AA-C26
Transport GX3 B-5887LIS B-5755N / B-5760N AC-C26 DK-C26 AA-C26
Transport LT B-5431 B-5755N / B-5760N AC-C26 DK-C26 AA-C26
Transport VX B-5887LIS B-5755N / B-5760N AC-C26 DK-C26 AA-C26
Transport XT B-5887LIS B-5755N / B-5760N AC-C26 DK-C26 AA-C26
Transport XT2 B-5887LIS B-5755N / B-5760N AC-C26 DK-C26 AA-C26
Transport ZX B-5887LIS B-5755N / B-5760N AC-C26 DK-C26 AA-C26

Panasonic

ToughBook 25 - B-5755J / B-5760J AC-B25 DK-B25 AA-B25
ToughBook 27 B-5933 B-5755J / B-5760J AC-B25 DK-B25 AA-B25
ToughBook 34 - B-5755J / B-5760J AC-B25 DK-B25 AA-B25
ToughBook 47 - B-5755J / B-5760J AC-B25 DK-B25 AA-B25
ToughBook 48 - B-5755J / B-5760J AC-B25 DK-B25 AA-B25
ToughBook 71 - B-5755J / B-5760J AC-B25 DK-B25 AA-B25
ToughBook 72 - B-5755J / B-5760J AC-B25 DK-B25 AA-B25

Sony

VAIO All-in-One FX Series B-5461 B-5755D / B-5760D AC-C25 DK-C25 AA-C25
VAIO C1 PictureBook - B-5755J / B-5760J AC-B25 DK-B25 AA-B25
VAIO PCG-505 series B-5464 B-5755J / B-5760J AC-B25 DK-B25 AA-B25
VAIO PCG-700 series B-5461 B-5755D / B-5760D AC-C25 DK-C25 AA-C25
VAIO PCG-800 series B-5461 B-5755D / B-5760D AC-C25 DK-C25 AA-C25
VAIO PCG-900 series B-5461 B-5755D / B-5760D AC-C25 DK-C25 AA-C25
VAIO PCG-C1F - B-5755J / B-5760J AC-B25 DK-B25 AA-B25
VAIO PCG-C1VN B-5464 - AC-B76 DK-B76 -
VAIO PCG-C1VP B-5464 - AC-B76 DK-B76 -
VAIO PCG-C1X - B-5755J / B-5760J AC-B25 DK-B25 AA-B25
VAIO PCG-C1XS B-5464 - AC-B76 DK-B76 -
VAIO PCG-F series B-5461 B-5755D / B-5760D AC-C25 DK-C25 AA-C25
VAIO PCG-FX series B-5461 B-5755D / B-5760D AC-C25 DK-C25 AA-C25
VAIO PCG-FXA series B-5461 B-5755D / B-5760D AC-C25 DK-C25 AA-C25
VAIO PCG-GR series B-5465 B-5755J / B-5760J AC-B25 DK-B25 AA-B25
VAIO PCG-GRS series B-5656 - AC-C25H - -
VAIO PCG-GRX series B-5656 - AC-C25H - -
VAIO PCG-N505 series B-5464 - AC-B76 DK-B76 -
VAIO PCG-NV series B-5656 - AC-C25H - -
VAIO PCG-R505 series B-5468 B-5755D / B-5760D AC-C25 DK-C25 AA-C25
VAIO PCG-SR series B-5462 B-5755J / B-5760J AC-B25 DK-B25 AA-B25
VAIO PCG-SRX series B-5462 B-5755J / B-5760J AC-B25 DK-B25 AA-B25
VAIO PCG-VX series B-5462 B-5755J / B-5760J AC-B25 DK-B25 AA-B25

Laptop Batteries & Adapters

Laptop Batteries & Adapters

8

Sony (cont.)

VAIO PCG-XG series B-5461 B-5755D / B-5760D AC-C25 DK-C25 AA-C25
VAIO PCG-Z505 series B-5463 B-5755D / B-5760D AC-C25 DK-C25 AA-C25

Toshiba

Portege 3000 series B-5343 - AC-B30 DK-B30 -
Satellite 1200 series B-5654 B-5755A / B-5760A AC-C10 DK-C10 AA-C10
Satellite 1400 series B-5333 B-5755H / B-5760H AC-B20 DK-B20 AA-B20
Satellite 1500 series B-5333 B-5755H / B-5760H AC-B20/G DK-B20 AA-B20
Satellite 1600 series B-5348 B-5755A / B-5760A AC-C10 DK-C10 AA-C10
Satellite 1700 series B-5347 B-5755A / B-5760A AC-C10 DK-C10 AA-C10
Satellite 1800 series B-5333 B-5755H / B-5760H AC-B20 DK-B20 AA-B20
Satellite 1900 series - - AC-C10H - -
Satellite 2000 series B-5333 B-5755H / B-5760H AC-B20/G DK-B20 AA-B20
Satellite 300 series B-5333 B-5755H / B-5760H AC-B20/G DK-B20 AA-B20
Satellite 3000 series B-5654 B-5755A / B-5760A AC-C10 DK-C10 AA-C10
Satellite 4000 series B-5333 B-5755H / B-5760H AC-B20/G DK-B20 AA-B20
Satellite 5000 series - B-5755H / B-5760H AC-B20 DK-B20 AA-B20
Satellite Pro 4000 series B-5333 B-5755H / B-5760H AC-B20 DK-B20 AA-B20
Satellite Pro 6000 series - B-5755H / B-5760H AC-B20 DK-B20 AA-B20
Tecra 8000 B-5342 B-5755H / B-5760H AC-B20 DK-B20 AA-B20
Tecra 8100 B-5346 B-5755H / B-5760H AC-B20 DK-B20 AA-B20
Tecra 8200 B-5350 B-5755H / B-5760H AC-B20 DK-B20 AA-B20
Tecra 9000 - B-5755H / B-5760H AC-B20 DK-B20 AA-B20
Tecra 9100 - B-5755H / B-5760H AC-B20 DK-B20 AA-B20

Winbook

Si series B-5417 B-5755A / B-5760A AC-C10 DK-C10 AA-C10
Si2 series B-5417 B-5755A / B-5760A AC-C10 DK-C10 AA-C10
XL B-5737, B-5765 B-5755A / B-5760A AC-C10 DK-C10 AA-C10
XL2 B-5729 - AC-C13 DK-C13 -
XL3 B-5729 - AC-C13 DK-C13 -
XLI B-5720, B-5765 B-5755A / B-5760A AC-C10 DK-C10 AA-C10
• Set of four plugs enables Hi-Capacity™ adapters to power the laptop and charge the battery anywhere in the world.

UPS Batteries

9

UPS Batteries

APC

450AT B-630 2
450AT+ B-630 2
520ES B-630 2
550ES B-630 2
AP1200 B-620 2
AP1200VS B-620 2
AP1200VX B-620 2
AP1250 B-615 2
AP1400 B-615 4
AP200 B-645 2
AP280 B-6855 1
AP330 B-610 1
AP330XT+ B-610 1
AP360 B-610 1
AP360SX B-610 1
AP450 B-630 2
AP520 B-630 2
AP600 B-610 2
AP800 B-630 4
AP800RT B-630 4
BackUPS 1250 B-615 2
BackUPS 1250B B-645 2
BackUPS 200 B-6800 1
BackUPS 200B B-6800 1
BackUPS 250 B-645 2
BackUPS 280 B-610 1
BackUPS 300 B-610 1
BackUPS 400 B-610 1

BackUPS 400B B-610 1
BackUPS 450 B-6820 1
BackUPS 500M B-610 1
BackUPS 600 B-6820 1
BackUPS 600C B-6820 1
BackUPS 650 B-630 1
BackUPS 650 Pro B-655 1
BackUPS 650M B-655 1
BackUPS 900 B-630 4
BackUPS Office 250 B-6805 1
BackUPS Office 280 B-6805 1
BackUPS Office 350 B-6805 1
BackUPS Office BF250 B-6805 1
BackUPS Office BF280 B-6805 1
BackUPS Office BF500 B-6805 1
BackUPS Pro 1000 B-6840 1
BackUPS Pro 1400 B-6835 1
BackUPS Pro 280 B-610 1

APC (cont.)

BackUPS Pro 420 B-610 1
BackUPS Pro 650 B-655 1
Network Powercell BD B-630 2
Personal Powercell B-610 1
Pro 350 USB B-610 1
Professional PowerCell B-610 1
SmartUPS 1000 B-6840 1
SmartUPS 1000NET B-6840 1
SmartUPS 1000RM B-6840 1
SmartUPS 1000XL B-6835 1
SmartUPS 1000XLNET B-6835 1
SmartUPS 1400 B-6835 1
SmartUPS 1400NET B-6835 1
SmartUPS 1400RM B-6845 1
SmartUPS 1400RMNET B-6845 1
SmartUPS 1400RMXLNET B-6855 1
SmartUPS 2000 B-615 4
SmartUPS 2200 B-6855 1
SmartUPS 2200NET B-6855 1
SmartUPS 2200RM B-6855 1
SmartUPS 2200RM3U B-6850 1
SmartUPS 2200XLT B-6855 1
SmartUPS 24XLBP B-6855 1
SmartUPS 250 B-645 3
SmartUPS 3000NET B-6855 1
SmartUPS 3000RM3U B-6850 1
SmartUPS 400 B-645 4
SmartUPS 420 B-610 1
SmartUPS 450 B-6810 1
SmartUPS 450Net B-6810 1
SmartUPS 48XLBP B-6855 1
SmartUPS 5000RMT5U B-6850 1
SmartUPS 600 B-610 2
SmartUPS 600LS B-610 2
SmartUPS 620NET B-655 1
SmartUPS 650 B-655 1
SmartUPS 700 B-6810 1
SmartUPS 700NET B-6810 1
SmartUPS 700RM B-6830 1
SmartUPS 700RMNet B-6830 1
SmartUPS 700XL B-6835 1
SmartUPS 700XLNET B-6835 1
SmartUPS 900 B-630 4
SmartUPS VS1000 B-6840 1
SmartUPS VS1400 B-6835 1
SmartUPS VS650 B-655 1

UPS Batteries

UPS Batteries

10

Best Technologies

Fortress 1050 B-610 4
Fortress 1422 B-610 4
LI-660VA B-610 2
Patriot 250 B-6805 1
Patriot 280 B-610 1
Patriot 420 B-610 1
SPS450 B-610 1

CyberPower Systems

CPS375SL B-617 1
CPS500SL B-610 1
CPS650SL B-610 1
OfficePower CPS700AVR B-610 1
OfficePower CPS900AVR B-610 2
Power99 CPS325VA B-6805 1
Power99 CPS385VA B-6805 1
Power99 CPS450VA B-6805 1
Power99 CPS500VA B-6805 1

Data Shield

800 B-620 2
AT1500 B-620 4
AT5000 B-655 2
AT800 (new) B-615 2
AT800 (old) B-620 2
PC200 B-630 2
ST550 B-630 2
ST675 B-615 1
Turbo 2+ B-630 1
Turbo XT300 B-615 1
Turbo XT350 B-615 1

Exide

2026C B-620 4
2036C B-620 6
PowerWare 1000K B-617 5
PowerWare Personal 500 B-662 3

Para Systems

A750 B-610 2
MinuteMan 1000 B-610 7
MinuteMan 1600 B-615 4
MinuteMan 250 B-610 1
MinuteMan 250XL B-630 2
MinuteMan 3000CP B-610 16
MinuteMan 300SS B-610 2
MinuteMan 450 B-610 1
MinuteMan 500 B-630 4
MinuteMan 550 B-630 4
MinuteMan 600 B-610 1
MinuteMan 600SS B-610 4
MinuteMan 900SS B-610 8
MinuteMan A500 B-630 2
MinuteMan AT650 B-610 1
MinuteMan PLM1250 B-610 4
MinuteMan Pro 200 B-617 1

Safe

1200 B-630 8
250 B-630 2
425 B-630 4
425A B-630 4
500 B-630 4
500A B-630 4
650 B-610 2

BP48 B-620 4
FES200A B-630 4
SM1400 B-630 8
SM650 B-610 2
SM800 B-630 4
SPS1000 B-630 8

Tripp Lite

325 B-620 1
425 B-620 1
450 B-620 1
450VA B-617 2
BC1000FC B-620 1
BC200 B-630 2
BC200-228B B-620 1
BC250 B-645 2
BC275 B-662 3
BC325A B-610 2
BC400 B-662 3
BC400 LAN B-645 3
BC400 Standby UPS B-610 1
BC420 B-610 1
BC450 B-610 1
BC450 LAN B-630 3
BC600LAN B-630 3
BC675 B-610 2
BC750 B-620 1
BC900 B-620 1
BC900 Lan B-620 1
BCPro 650 B-630 2
CP 350 B-610 2
Office 500 B-610 1
OM1995 B-610 3
Omni 450LAN B-620 1
Omni 500LAN B-630 1
OmniPro 675 B-630 2
OmniPro 850 B-610 4
OmniPro 900 B-620 1
OmniSmart 450 B-610 1
OmniSmart 675 B-630 2
Smart 1400 B-630 6
Smart 400 B-610 1
Smart 600 B-610 3
Smart 900 B-630 1
Smart UPS 400 B-600 4
Touchmaster 420 B-645 3

Camcorder Batteries & Chargers

11

Camcorder Batteries & Chargers

Canon

Elura B-9521, B-9535 CH-9005
Elura 10 B-9561, B-9562, B-9563 CH-9004
Elura 10MC B-9561, B-9562, B-9563 CH-9004
Elura 2 B-9561, B-9562, B-9563 CH-9004
Elura 20 B-9561, B-9562, B-9563 CH-9004
Elura 20MC B-9561, B-9562, B-9563 CH-9004
Elura 2MC B-9561, B-9562, B-9563 CH-9004
Elura 40MC B-9581 CH-9001
ES300V B-9534, B-972, B-973 CH-9006
ES4000 B-9534, B-972, B-973 CH-9006
ES5000 B-9534, B-972, B-973 CH-9006
ES6000 B-9534, B-972, B-973 CH-9006
ES6500 B-9534, B-972, B-973 CH-9006
ES7000V B-9534, B-972, B-973 CH-9006
ES8000 B-9534, B-972, B-973 CH-9006

ES8100V B-9534, B-972, B-973 CH-9006
ES8200V B-9534, B-972, B-973 CH-9006
GL-1 B-9534, B-972, B-973 CH-9006
GL2 B-9534, B-972, B-973 CH-9006
Optura B-9534, B-972, B-973 CH-9006
Optura 200MC B-9552, B-9553 CH-9002
Optura Pi B-9552, B-9553 CH-9002
XL1 B-9534, B-972, B-973 CH-9006
ZR B-9521, B-9535 CH-9005
ZR-10 B-9552, B-9553 CH-9002
ZR-20 B-9552, B-9553 CH-9002
ZR-40 B-9552, B-9553 CH-9002
ZR-45 MC B-9552, B-9553 CH-9002
ZR-50 MC B-9552, B-9553 CH-9002
ZR-60 B-9552, B-9553 CH-9002
ZR-65MC B-9552, B-9553 CH-9002
ZR-70MC B-9552, B-9553 CH-9002

Hitachi

VM-1300 B-9502 -
VM-2250A B-9503 -
VM-2300A B-9502 -
VM-2380 B-9503 -
VM-2400E B-997, B-9971 -
VM-3800A B-9502 -
VM-5400A B-9502 -
VM-645LA B-9509, B-987 CH-9000
VM-E10A B-997, B-9971 -
VM-E220A B-997 -

Hitachi (cont.)

VM-E25A B-997, B-9971 -
VM-E310 B-997, B-9971 -
VM-E44 B-997, B-9971 -
VM-E510A B-997, B-9971 -
VM-E530A B-9509, B-987 CH-9000
VM-E53A B-997, B-9971 -
VM-E54A B-997, B-9971 -
VM-E710A B-997, B-9971 -
VM-H100LA B-9509, B-987 CH-9000
VM-H18A B-997, B-9971 -
VM-H710A B-997 -
VM-S7200A B-9503 -

JVC

CR-C7U B-984 -
GF-500U B-984 -
GR-277 B-974 -
GR-30U B-984 -
GR-505 B-984 -
GR-A30 B-984 -
GR-A60U B-984 -
GR-AW1 B-974 -
GR-AX26U B-974 -
GR-AX35 B-974 -
GR-AX400U B-974 -
GR-AX47U B-974 -
GR-AX500 B-974 -
GR-AX606U B-974 -
GR-AX720 B-974 -
GR-AX800U B-974 -
GR-AX900U B-974 -
GR-AX930U B-974 -
GR-AXM1000U B-974 -
GR-AXM700U B-974 -
GR-AXM900U B-974 -
GR-C25U B-984 -
GR-C707 B-984 -
GR-DV1 B-988 CH-9008

GR-DV1U B-988 CH-9008
GR-DV3U B-9522 -
GR-DV9000 B-9509, B-987 CH-9000
GR-DVA1 B-974 -
GR-DVAX B-9537 CH-9015
GR-DVF10 B-974 -

Camcorder Batteries & Chargers

Camcorder Batteries & Chargers

12

JVC (cont.)

GR-DVF11 B-9530 CH-9013
GR-DVF21 B-9530 CH-9013
GR-DVF21U B-9530 CH-9013
GR-DVF31 B-9530 CH-9013
GR-DVF31U B-9530 CH-9013
GR-DVF505U B-9554, B-9555, B-9556 CH-9012
GR-DVL100 B-9554, B-9555, B-9556 CH-9012
GR-DVL145 B-9554, B-9555, B-9556 CH-9012
GR-DVL210 B-9554, B-9555, B-9556 CH-9012
GR-DVL300 B-9554, B-9555, B-9556 CH-9012
GR-DVL500U B-9554, B-9555, B-9556 CH-9012
GR-DVL505U B-9554, B-9555, B-9556 CH-9012
GR-DVL520U B-9554, B-9555, B-9556 CH-9012
GR-DVL720U B-9554, B-9555, B-9556 CH-9012
GR-DVL725U B-9554, B-9555, B-9556 CH-9012
GR-DVL805 B-9554, B-9555, B-9556 CH-9012
GR-DVL805U B-9554, B-9555, B-9556 CH-9012
GR-DVL815U B-9554, B-9555, B-9556 CH-9012
GR-DVL820U B-9554, B-9555, B-9556 CH-9012
GR-DVL9500 B-9522, B-9538 -
GR-DVL9800U B-9522, B-9538 -
GR-DVM5U B-9522, B-9538 -
GR-DVM70U (dark grey) B-9539, B-9540 CH-9014
GR-DVM76U B-9604, B-9605 CH-9012
GR-DVM96U B-9604, B-9605 CH-9012
GR-DVP3 B-9571, B-9572 CH-9011
GR-DVX B-9537 CH-9015
GR-DVXU B-9537 CH-9015
GR-S500U B-984 -
GR-S7 B-974 -
GR-S70EG B-984 -
GR-SX90 B-974 -
GR-SXM240U B-974 -
GR-SXM340U B-974 -
GR-SXM520U B-974 -
GR-SZ1 B-974 -

Panasonic

AG-DVC7 B-9523, B-9524, B-9557 CH-9018
PK-700 B-978 CH-978
PK-802 B-977 CH-978
PV-21D B-974 -
PV-300 B-977 CH-978
PV-500 B-978 CH-978

Panasonic (cont.)

PV-800 B-978 CH-978
PV-900 B-978 CH-978
PV-D300 B-974 -
PV-DC152 B-9523, B-9524, B-9557 CH-9018
PV-DC252 B-9523, B-9524, B-9557 CH-9018
PV-DC352 B-9523, B-9524, B-9557 CH-9018
PV-DV100 B-9523, B-9524, B-9557 CH-9018
PV-DV1000 B-987 -
PV-DV102 B-9523, B-9524, B-9557 CH-9018
PV-DV200 B-9523, B-9524, B-9557 CH-9018

PV-DV202 B-9523, B-9524, B-9557 CH-9018
PV-DV400 B-9523, B-9524, B-9557 CH-9018
PV-DV402 B-9523, B-9524, B-9557 CH-9018
PV-DV52 B-9523, B-9524, B-9557 CH-9018
PV-DV600 B-9523, B-9524, B-9557 CH-9018
PV-DV701 B-9523, B-9524, B-9557 CH-9018
PV-DV702 B-9523, B-9524, B-9557 CH-9018
PV-DV852 B-9523, B-9524, B-9557 CH-9018
PV-DV900 B-9523, B-9524, B-9557 CH-9018
PV-DV910 B-9523, B-9524, B-9557 CH-9018
PV-DV952 B-9523, B-9524, B-9557 CH-9018
PV-L352 B-974 -
PV-L452 B-974 -
PV-L552 B-974 -
PV-L652 B-974 -
PV-VM202 B-9523, B-9524, B-9557 CH-9018
VDR-M20 B-9523, B-9524, B-9557 CH-9018

Philips

VKR-2000 B-977 CH-978
VKR-6800 B-980 -
VKR-9000 B-984 -

RCA

CC-180 B-9502 -
CC-260 B-9503 -
CC-305 B-9503 -
CC-405 B-9502 -
CC-8251 B-9509, B-987 CH-9000
CC-9390 B-9528, B-9544, B-9545 CH-9023
PRO-800 B-959 -
PRO-852 B-997, B-9971 -

Camcorder Batteries & Chargers

13

Camcorder Batteries & Chargers

RCA (cont.)

PRO-854 B-959 -
PRO-V600 B-9741 -
PRO-V700C B-974 -
PRO-V712 B-989 -
PRO-V714 B-989 -
PRO-V730 B-987 CH-9000
PRO-V742 B-987 CH-9000
PRO-598 B-961, B-962 CH-9000
PRO-807 B-956, B-9741 -
PRO-815 B-997, B-9971 -
PRO-842 B-959 -
PRO-847 B-959 -
PRO-850 B-997, B-9971 -

Samsung

SC-L520 B-9565, B-9566, B-9567 CH-9006
SC-L540 B-9565, B-9566, B-9567 CH-9006
SC-L610 B-9565, B-9566, B-9567 CH-9006
SC-L700 B-9565, B-9566, B-9567 CH-9006
SC-L750 B-9565, B-9566, B-9567 CH-9006
SC-L800 B-956 -
SC-M51 B-9565, B-9566, B-9567 CH-9006
SC-M52 B-9565, B-9566, B-9567 CH-9006
SC-M53 B-9565, B-9566, B-9567 CH-9006
SC-M62 B-9565, B-9566, B-9567 CH-9006
SC-D130 B-9602, B-9603 CH-9006
SC-L810 B-9565, B-9566, B-9567 CH-9006
SC-W80 B-9565, B-9566, B-9567 CH-9006
VP-D55 B-9602, B-9603 CH-9006

VP-L530 B-9565, B-9566, B-9567 CH-9006
VP-L550 B-9565, B-9566, B-9567 CH-9006
VP-L750 B-9565, B-9566, B-9567 CH-9006
VP-M50 B-9565, B-9566, B-9567 CH-9006
VP-M51 B-9565, B-9566, B-9567 CH-9006
VP-M53 B-9565, B-9566, B-9567 CH-9006
VP-M54 B-9565, B-9566, B-9567 CH-9006
VP-W75 B-9565, B-9566, B-9567 CH-9006

Sharp

VL-630U B-9531, B-990 -
VL-A10H B-9531, B-990 -
VL-A111U B-9531, B-990 -
VL-A45U B-9531, B-990 -

Sharp (cont.)

VL-AD260U B-9528, B-9544, B-9545 CH-9023
VL-AH130 B-9531, B-990 -
VL-AH131U B-9531, B-990 -
VL-AH150U B-9531, B-990 -
VL-AH151U B-9531, B-990 -
VL-AH160U B-9531, B-990 -
VL-AH161U B-9531, B-990 -
VL-AH50 B-9531, B-990 -
VL-AH500U B-9531, B-990 -
VL-AH50U B-9531, B-990 -
VL-AH60U B-9531, B-990 -
VL-D5000 B-995, B-996 CH-9021
VL-DC1 B-995 CH-9021
VL-E33U B-989 -
VL-E34U B-989 -
VL-E37U B-989 -
VL-E39U B-989 -
VL-E43U B-989 -
VL-E46U B-989 -
VL-E500 B-995, B-996 CH-9021
VL-E500U B-989 -
VL-E600U B-989 -
VL-E630U B-9531, B-990 -
VL-E680U B-9531, B-990 -
VL-E685U B-9531, B-990 -
VL-E700U B-989 -
VL-E765U B-9531, B-990 -
VL-H420U B-989 -
VL-H800U B-9531, B-990 -
VL-H850U B-9531, B-990 -
VL-H860U B-9528, B-9544, B-9545 CH-9023
VL-H870U B-9528, B-9544, B-9545 CH-9023
VL-H880U B-9528, B-9544, B-9545 CH-9023
VL-H890U B-9528, B-9544, B-9545 CH-9023
VL-NZ105U B-9584, B-9585, B-9586 CH-9022
VL-NZ150U B-9584, B-9585, B-9586 CH-9022
VL-NZ55U B-9584, B-9585, B-9586 CH-9022
VL-SD20U B-9528, B-9544, B-9545 CH-9023
VL-SE20U B-9531, B-990 -
VL-SE50U B-9531, B-990 -

Sony

CCD-F150 B-956, B-9741 -
CCD-F330 B-956, B-9741 -

Camcorder Batteries & Chargers

Camcorder Batteries & Chargers

14

Sony (cont.)

CCD-F330 B-956, B-9741 -

CCD-SC5 B-961 CH-9000
CCD-TR200 B-961, B-962, B-963 CH-9000
CCD-TR330 B-956, B-9741 -
CCD-TR416 B-961, B-962, B-963 CH-9000
CCD-TR700 B-956, B-9741 -
CCD-TR930 B-961, B-962, B-963 CH-9000
CCD-TRV108 B-9547, B-9548, B-9549 CH-9000
CCD-TRV118 B-9547, B-9548, B-9549 CH-9000
CCD-TRV15 B-961, B-962, B-963 CH-9000
CCD-TRV208 B-9547, B-9548, B-9549 CH-9000
CCD-TRV3000 B-961, B-962, B-963 CH-9000
CCD-TRV308 B-9547, B-9548, B-9549 CH-9000
CCD-TRV318 B-9547, B-9548, B-9549 CH-9000
CCD-TRV408 B-9547, B-9548, B-9549 CH-9000
CCD-TRV48 B-961, B-962, B-963 CH-9000
CCD-TRV52 B-956, B-9741 -
CCD-TRV608 B-9547, B-9548, B-9549 CH-9000
CCD-TRV615 B-961, B-962, B-963 CH-9000
CCD-TRV68 B-961, B-962, B-963 CH-9000
CCD-TRV730 B-9547, B-9548, B-9549 CH-9000
CCD-TRV740 B-9547, B-9548, B-9549 CH-9000
CCD-TRV815 B-961, B-962, B-963 CH-9000
CCD-TRV940 B-961, B-962, B-963 CH-9000
DCR-IP220 B-9593, B-9594 CH-9000
DCR-IP5 B-9593, B-9594 CH-9000
DCR-IP55 B-9593, B-9594 CH-9000
DCR-IP7 B-9593, B-9594 CH-9000
DCR-PC100 B-9547, B-9548, B-9549 CH-9000
DCR-PC101 B-9547, B-9548, B-9549 CH-9000
DCR-PC120BT B-9547, B-9548, B-9549 CH-9000
DCR-PC7 B-9508, B-9546 CH-9000
DCR-TRV10 B-9547, B-9548, B-9549 CH-9000
DCR-TRV110 B-961, B-962, B-963 CH-9000
DCR-TRV18 B-9547, B-9548, B-9549 CH-9000
DCR-TRV19 B-9547, B-9548, B-9549 CH-9000
DCR-TRV20 B-9547, B-9548, B-9549 CH-9000
DCR-TRV22 B-9547, B-9548, B-9549 CH-9000
DCR-TRV25 B-9547, B-9548, B-9549 CH-9000
DCR-TRV250 B-9547, B-9548, B-9549 CH-9000
DCR-TRV27 B-9547, B-9548, B-9549 CH-9000
DCR-TRV320 B-961, B-962, B-963 CH-9000
DCR-TRV33 B-9547, B-9548, B-9549 CH-9000
DCR-TRV350 B-9547, B-9548, B-9549 CH-9000
DCR-TRV38 B-9547, B-9548, B-9549 CH-9000
DCR-TRV39 B-9547, B-9548, B-9549 CH-9000

Sony (cont.)

DCR-TRV40 B-9547, B-9548, B-9549 CH-9000
DCR-TRV50 B-9547, B-9548, B-9549 CH-9000
DCR-TRV70 B-9547, B-9548, B-9549 CH-9000
DCR-TRV740 B-9547, B-9548, B-9549 CH-9000
DCR-TRV8 B-9547, B-9548, B-9549 CH-9000
DCR-TRV80 B-9547, B-9548, B-9549 CH-9000
DCR-VX2000 B-961, B-962, B-963 CH-9000
DSR-PD150 B-961, B-962, B-963 CH-9000

Additional plates available

- Works with most 3.6 / 3.7 / 7.2 / 7.4V Li-Ion batteries
- Includes three plates for most common batteries
- Fully charges a battery in as few as 28 minutes
- Over-voltage and short circuit protection for total charge safety
- Four step LCD fuel gauge to indicate charge status
- Can be used with 100-240V AC or 12V DC power source
- Includes ultra slim AC adapter and car adapter
- UL, CE certified
- One year warranty

Digital Camera Batteries & Chargers

Digital Camera Batteries & Chargers

Canon

EOS-D30 B-9552 CH-9002
PowerShot 70 B-9582 -
PowerShot A100 B-162 -
PowerShot A200 B-162 -
PowerShot A30 B-162 -
PowerShot A40 B-162 -
PowerShot A50 B-9558 -
PowerShot G1 B-9552 CH-9002
PowerShot G2 B-9552 CH-9002
PowerShot G3 B-9552 CH-9002
PowerShot Pro90 IS B-9552 CH-9002
PowerShot S10 B-9558 -
PowerShot S100 B-9568 CH-9003
PowerShot S110 B-9568 CH-9003
PowerShot S20 B-9558 -
PowerShot S200 B-9568 CH-9003
PowerShot S230 B-9568 CH-9003
PowerShot S30 B-9581 CH-9001
PowerShot S300 B-9568 CH-9003
PowerShot S330 B-9568 CH-9003
PowerShot S40 B-9581 CH-9001
PowerShot S45 B-9581 CH-9001

Casio

Exilim EX-M1 B-9611 -
Exilim EX-M2 B-9611 -
Exilim EX-S1 B-9611 -
Exilim EX-S2 B-9611 -
Exilim EX-Z3 B-9611 -
QV-5700 B-162 -

Fuji

DS260 B-9560 -
FinePix 2650Zoom B-160 -
FinePix 4800Zoom B-9559 CH-9008
FinePix 4900Zoom B-9559 CH-9008
FinePix 50i B-9583 CH-9007
FinePix 6800Zoom B-9559 CH-9008
FinePix 6900Zoom B-9559 CH-9008
FinePix A101 B-160 -
FinePix F401 B-9583 CH-9007
FinePix F601 B-9583 CH-9007

Fuji (cont.)

FinePix M603 B-9583 CH-9007
MX-1700 B-9559 CH-9008
MX-2700 B-9559 CH-9008
MX-2900 B-9559 CH-9008
MX-600 B-9560 -
MX-600Z B-9560 -
MX-6800 B-9559 CH-9008
MX-6900 B-9559 CH-9008
MX-700 B-9560 -

Hewlett Packard

PhotoSmart 120 B-162 -
PhotoSmart 210 B-3501 -
PhotoSmart 215 B-3501 -
PhotoSmart 215xi B-3501 -
PhotoSmart 315 B-162 -
PhotoSmart 315xi B-162 -
PhotoSmart 318 B-162 -
PhotoSmart 318xi B-162 -
PhotoSmart 320 B-162 -
PhotoSmart 320xi B-162 -

PhotoSmart 612 B-162 -
PhotoSmart 612xi B-162 -
PhotoSmart 618 B-162 -
PhotoSmart 618xi B-162 -
PhotoSmart 620 B-162 -
PhotoSmart 620xi B-162 -
PhotoSmart 715 B-162 -
PhotoSmart 715xi B-162 -
PhotoSmart 720 B-162 -
PhotoSmart 720xi B-162 -
PhotoSmart 812 B-162 -
PhotoSmart 812xi B-160 -
PhotoSmart 850 B-162 -
PhotoSmart 850xi B-162 -
PhotoSmart 912 B-162 -
PhotoSmart 912xi B-162 -
PhotoSmart C20 B-162 -
PhotoSmart C200 B-162 -
PhotoSmart C200cl B-162 -
PhotoSmart C200xi B-162 -
PhotoSmart C30 B-162 -
PhotoSmart C500 B-161 -
PhotoSmart C500xi B-161 -

Digital Camera Batteries & Chargers

16

Digital Camera Batteries & Chargers

JVC

GC-QX3 B-9569 CH-9010
GC-QX3U B-9569 CH-9010
GC-S5 B-9560 -

Kodak

DC 4800 B-9559 CH-9008
DX3900 B-155, B-9576 -
DX4330 B-155, B-9576 -
DX4900 B-155, B-9576 -
LS443 B-9583 CH-9007

Konica

Revio KD-310 B-9597 -
Revio KD-310Z B-9597 -
Revio KD-400Z B-9597 -

Minolta

Dimage X B-9590 -
Dimage Xi B-9590 -

Nikon

Coolpix 2500 B-9589 CH-9017
Coolpix 3500 B-9589 CH-9017
CoolPix 4300 B-9570 CH-9016
CoolPix 4500 B-9570 CH-9016
CoolPix 5000 B-9570 CH-9016
CoolPix 5700 B-9570 CH-9016
Coolpix 995 B-9570 CH-9016

Olympus

Camedia C-3000 Zoom B-155, B-162 -
Camedia C-3030 Zoom B-155, B-162 -
Camedia C-3040 Zoom B-155, B-162 -
Camedia C-4000 Zoom B-155, B-162 -
Camedia C-5050 Zoom B-155, B-162 -
D-460 B-155, B-160 -

Panasonic

Lumix DMC-F7 B-9577 CH-9020
Lumix DMC-LC40K B-9591 -
Lumix DMC-LC40S B-9591 -
Lumix DMC-LC5-S B-9591 -
Lumix DMC-LC5K B-9591 -

Pentax

Optio 230 B-155, B-160 -
Optio 330 B-9583 CH-9007
Optio 430 B-9583 CH-9007

Polaroid

PDC-1050 B-155, B-162 -
PDC-2150 B-162 -

Samsung

AFZoom 770 B-150 -

Sony

DF-1 B-9519 -
DKC-FP3 B-961 CH-9000
DSC-700 B-961 CH-9000
DSC-770 B-961 CH-9000
DSC-D700 B-961 CH-9000
DSC-F505 B-9580 -
DSC-F505V B-9580 -
DSC-F707 B-9547 CH-9000
DSC-F717 B-9547 CH-9000
DSC-F77 B-9596 CH-9027
DSC-P2 B-9596 CH-9027
DSC-P20 B-160, B-9580 -
DSC-P3 B-9596 CH-9027
DSC-P30 B-9580 -
DSC-P31 B-160 -
DSC-P32 B-160 -
DSC-P5 B-9596 CH-9027
DSC-P50 B-9580 -
DSC-P51 B-160 -
DSC-P52 B-160 -
DSC-P7 B-9596 CH-9027

Digital Camera Batteries & Chargers

17

Digital Camera Batteries & Chargers

Sony (cont.)

DSC-P71 B-160 -
DSC-P72 B-160 -
DSC-P9 B-9596 CH-9027
DSC-S30 B-9547 CH-9000
DSC-S50 B-9547 CH-9000
DSC-S70 B-9547 CH-9000
DSC-S75 B-9547 CH-9000
DSC-S85 B-9547 CH-9000
Mavica MVC-CD1000 B-961 CH-9000
Mavica MVC-CD200 B-961 CH-9000
Mavica MVC-CD250 B-9547 CH-9000
Mavica MVC-CD300 B-9547 CH-9000
Mavica MVC-CD400 B-9547 CH-9000
Mavica MVC-CHF81 B-961 CH-9000
Mavica MVC-FD100 B-961 CH-9000
Mavica MVC-FD200 B-961 CH-9000
Mavica MVC-FD5 B-961 CH-9000
Mavica MVC-FD51 B-961 CH-9000
Mavica MVC-FD7 B-961 CH-9000
Mavica MVC-FD71 B-961 CH-9000

Mavica MVC-FD73 B-961 CH-9000
Mavica MVC-FD75 B-961 CH-9000
Mavica MVC-FD81 B-961 CH-9000
Mavica MVC-FD83 B-961 CH-9000
Mavica MVC-FD85 B-961 CH-9000
Mavica MVC-FD87 B-961 CH-9000
Mavica MVC-FD88 B-961 CH-9000
Mavica MVC-FD90 B-961 CH-9000
Mavica MVC-FD91 B-961 CH-9000
Mavica MVC-FD92 B-961 CH-9000
Mavica MVC-FD95 B-961 CH-9000

Toshiba

PDR-2300 B-162 -
PDR-3300 B-162 -
PDR-M3 B-9560 -
PDR-M4 B-9559 CH-9008
PDR-M5 B-9559 CH-9008
PDR-M70 B-9559 CH-9008

Vivitar

ViviCam 10 B-160 -
ViviCam 20 B-160 -
ViviCam 3640 B-162 -
Additional plates available

Universal Ultra Fast Digital Camera Battery Charger

Part Number: CH-9600

- Works with most 3.6 / 3.7 / 7.2 / 7.4V Li-Ion batteries
- Includes three plates for most common batteries
- Fully charges a battery in as few as 28 minutes
- Over-voltage and short circuit protection for total charge safety
- Four step LCD fuel gauge to indicate charge status
- Can be used with 100-240V AC or 12V DC power source
- Includes ultra slim AC adapter and car adapter
- UL, CE certified
- One year warranty

Cell Phone Batteries & Accessories

Cell Phone Batteries & Accessories

18

Alcatel

HC400 B-7510, B-7511 - -
HC600 B-7510, B-7511 - -
HC800 B-7510, B-7511 - -

AT&T

3810 B-7563 - CH-719
3810A B-7563 - CH-719
3812 B-7563 - CH-719
3815 B-7563 - CH-719
3830 B-7566 DK-723 CH-720
3850 B-7570, B-7571 DK-723 CH-722
6650 B-7574, B-774 DK-723 CH-721

Audiovox

401 B-7581 DK-705 CH-700
405 B-7581 DK-705 CH-700
406 B-7581 DK-705 CH-700
440 B-7502, B-7579 DK-700 -
470 B-7502, B-7579 DK-700 -

480 B-7502 DK-700 -
501 B-7581 DK-705 CH-700
505 B-7581 DK-705 CH-700
507 B-7581 DK-705 CH-700
CDM-3000 B-7611, B-7612 DK-707 -
CDM-3000XL B-7611, B-7612 DK-707 -
CDM-9100 B-7641 - -
MVX401 B-7581 DK-705 CH-700
MVX405 B-7581 DK-705 CH-700
MVX406 B-7581 DK-705 CH-700
MVX440 B-7502, B-7579 DK-700 -
MVX470 B-7502, B-7579 DK-700 -
MVX480 B-7502 DK-700 -
MVX501 B-7581 DK-705 CH-700
MVX505 B-7581 DK-705 CH-700
MVX506 B-7581 DK-705 CH-700
MVX507 B-7581 DK-705 CH-700
MVX605 B-7507 - -
MVX800 B-7586 DK-704 CH-701
MVX805 B-7586 DK-704 CH-701
MVX850 B-7586 DK-704 CH-701
MVX855 B-7586 DK-704 CH-701
PCX-1000 B-7613 - -

Bosch

908 B-7515, B-7516 - -
909 B-7515, B-7516 - -

Ericsson

197 B-765, B-795 DK-708 CH-716
200 B-765, B-795 DK-708 CH-716
237 B-765, B-795 DK-708 CH-716
300 B-765, B-795 DK-708 CH-716
338 B-765, B-795 DK-708 CH-716
600 B-769, B-798 DK-710 -
618 B-769, B-798 DK-710 -
620 B-769, B-798 DK-710 -
628 B-769, B-798 DK-710 -
630 B-769, B-798 DK-710 -
738 B-785 DK-710 -
788 B-785 DK-710 -
A1228C B-769, B-798 DK-710 -
A1228LX B-769, B-798 DK-710 -
AF738 B-785 DK-710 -
AF788 B-785 DK-710 -
AH200 B-765, B-795 DK-708 CH-716
AH203 B-765, B-795 DK-708 CH-716
AH210 B-765, B-795 DK-708 CH-716
AH220 B-765, B-795 DK-708 CH-716
AH230 B-765, B-795 DK-708 CH-716
AH237 B-765, B-795 DK-708 CH-716
AH300 B-765, B-795 DK-708 CH-716
AH310 B-765, B-795 DK-708 CH-716
AH320 B-765, B-795 DK-708 CH-716
AH337 B-765, B-795 DK-708 CH-716
AH338 B-765, B-795 DK-708 CH-716
AH600 B-769, B-798 DK-710 -
AH618 B-769, B-798 DK-710 -
AH620 B-769, B-798 DK-710 -
AH628 B-769, B-798 DK-710 -
AH630 B-769, B-798 DK-710 -
CF388 B-765, B-795 DK-708 CH-716
CF768 B-785 DK-710 -
CF788 B-785 DK-710 -
CF888 B-769, B-798 DK-710 -
DF363 B-765, B-795 DK-708 CH-716
DH210 B-765, B-795 DK-708 CH-716
DH336 B-765, B-795 DK-708 CH-716
DH338 B-765, B-795 DK-708 CH-716

Cell Phone Batteries & Accessories

19

Cell Phone Batteries & Accessories

Ericsson (cont.)

DH353 B-765, B-795 DK-708 CH-716
DH668 B-769, B-798 DK-710 -
EH237 B-765, B-795 DK-708 CH-716
ER237 B-765, B-795 DK-708 CH-716
ER336 B-765, B-795 DK-708 CH-716
GA318 B-765, B-795 DK-708 CH-716
GA628 B-769, B-798 DK-710 -
GF768 B-785 DK-710 -
GF788 B-785 DK-710 -
GH337 B-765, B-795 DK-708 CH-716
GH388 B-765, B-795 DK-708 CH-716
GH688 B-769, B-798 DK-710 -
KF788 B-785 DK-710 -
KH668 B-769, B-798 DK-710 -
LX100 B-765, B-795 DK-708 CH-716
LX600 B-769, B-798 DK-710 -
LX677 B-769, B-798 DK-710 -
LX700 B-769, B-798 DK-710 -
LX77 B-765, B-795 DK-708 CH-716
Micro Portable Flip B-765, B-795 DK-708 CH-716
NH237 B-765, B-795 DK-708 CH-716
PC337 B-765, B-795 DK-708 CH-716
R280 B-769, B-798 DK-710 -
R280D B-769, B-798 DK-710 -
R280LX B-769, B-798 DK-710 -
R289LX B-769, B-798 DK-710 -
SH888 B-769, B-798 DK-710 -
T18 B-785 DK-710 -
T18D B-785 DK-710 -
T19LX B-785 DK-710 -
TKA01 B-765, B-795 DK-708 CH-716
TKA02 B-765, B-795 DK-708 CH-716
TKA41 B-765, B-795 DK-708 CH-716
TKG01 B-765, B-795 DK-708 CH-716
TKG12 B-765, B-795 DK-708 CH-716

GE

CT-3000 B-765, B-795 DK-708 CH-716
CT-510 B-765, B-795 DK-708 CH-716
CT-550 B-765, B-795 DK-708 CH-716
CT-600 B-769, B-798 DK-710 -
CT-618 B-769, B-798 DK-710 -
CT-620 B-769, B-798 DK-710 -
CT-640 B-769, B-798 DK-710 -

GE (cont.)

CT-650 B-769, B-798 DK-710 -
CT-700 B-765, B-795 DK-708 CH-716
CT-800 B-765, B-795 DK-708 CH-716
DT-3500 B-765, B-795 DK-708 CH-716
Flipfone B-765, B-795 DK-708 CH-716

JVC

TN-J10 B-755, B-783 DK-713 CH-717
TN-J7 B-755, B-783 DK-713 CH-717

LG Electronics

LG-TM510 (Black) B-7642 DK-7630 -
LG-TM510 (Silver) B-7630 DK-7630 -
TouchPoint 2100 B-7552 DK-7552 -
TouchPoint 2110 B-7552 DK-7552 -

Mitsubishi

AH127 B-7500 - -
AH129 B-7500 - -
AH131 B-7500 - -
M129 B-7500 - -

Motorola

88015 B-755, B-783 DK-713 CH-717
88017 B-755, B-783 DK-713 CH-717
88018 B-755, B-783 DK-713 CH-717
900 B-755, B-783 DK-713 CH-717
950PT B-755, B-783 DK-713 CH-717
GSM 8400 B-755, B-783 DK-713 CH-717
M-70 B-755, B-783 - CH-717
M-80 B-755, B-783 DK-713 CH-717
MicroTac series B-755, B-783 DK-713 CH-717
Nextel i30sx B-7557, B-7651 DK-7557 -
Nextel i35s B-7557, B-7651 DK-7557 -
Nextel i50sx B-7557, B-7561 DK-7557 -
Nextel i55sr B-7557, B-7561 DK-7557 -
Nextel i60c B-7557, B-7568 DK-7557 -
Nextel i85 B-7557, B-7561 DK-7557 -
Nextel i85s B-7557, B-7561 DK-7557 -
Nextel i88s B-7557, B-7561 DK-7557 -

Cell Phone Batteries & Accessories

Cell Phone Batteries & Accessories

20

Motorola (cont.)

Nextel i90 B-7557, B-7565 DK-7557 -
Nextel i90c B-7557, B-7565 DK-7557 -
Nextel i95cl B-7557, B-7559 DK-7557 -
StarTac series B-763, B-764 DK-715 CH-715
T193 B-7551 - -
T193M B-7551 - -
T720 B-7649 DK-7557 -
TalkAbout T2260 B-7636 - -
TalkAbout T2297 B-7636 - -
TeleTAC series B-755, B-783 DK-713 CH-717
TimePort L7089 B-790 DK-715 CH-706
V Phone 3600 series B-790 DK-715 CH-706
V Phone L2000 B-790 DK-715 CH-706
V2260 B-7636 - -
V2282 B-7636 - -
V2397 B-7636 - -
V2660 B-7636 - -
V60series B-7557, B-7558 DK-7557 -
V8160 B-790 DK-715 CH-706
Vader B-790 DK-715 CH-706
Vader 3620 B-7636 - -

NEC

120 - DK-719 CH-718
2000 B-780 DK-722 CH-708
700 B-780 DK-722 CH-708
701 B-780 DK-722 CH-708
800 B-780 DK-722 CH-708
810 B-780 DK-722 CH-708
820 B-780 DK-722 CH-708
G-800 B-780 DK-722 CH-708
P-7 B-780 DK-722 CH-708
P-8 B-780 DK-722 CH-708
P2000 B-780 DK-722 CH-708
P700 B-780 DK-722 CH-708
P701 B-780 DK-722 CH-708

P800 B-780 DK-722 CH-708
P810 B-780 DK-722 CH-708
P820 B-780 DK-722 CH-708

Nextel

i1000 B-794, B-7941 DK-717 -
i1000 Plus B-794, B-7941 DK-717 -

Nextel (cont.)

i2000 B-794, B-7941 DK-717 -
i30sx B-7557, B-7651 DK-7557 -
i35s B-7557, B-7651 DK-7557 -
i370 B-7629, B-7631 DK-716 -
i390 B-7629, B-7631 DK-716 -
i55sr B-7557, B-7561 DK-7557 -
i600 B-7629, B-7631 DK-716 -
i60c B-7557, B-7568 DK-7557 -
i88s B-7557, B-7561 DK-7557 -
i90 B-7557, B-7565 DK-7557 -
i90c B-7557, B-7565 DK-7557 -
i95cl B-7557, B-7559 DK-7557 -
iDen 1600 B-7629, B-7631 DK-716 -
iDen 370 B-7629, B-7631 DK-716 -
iDen 600 B-7629, B-7631 DK-716 -
ip370 B-7629, B-7631 DK-716 -
iR370 B-7629, B-7631 DK-716 -

Nokia

100 B-7563 - CH-719
1000 B-7566 DK-723 CH-720
101 B-7566 DK-723 CH-720
105 B-7563 - CH-719
121 B-7566 DK-723 CH-720
128 B-7566 DK-723 CH-720
201 B-7566 DK-723 CH-720
2100 series B-7574, B-774 DK-723 CH-721
232 B-7570, B-7571 DK-723 CH-722
239 B-7570, B-7571 DK-723 CH-722
252 B-771 DK-725 -
3110 B-7503 DK-725 -
3310 B-7503 DK-725 -
3360 B-7503 DK-725 -
3390 B-7503 DK-725 -
3395 B-7503 DK-725 -
3810 B-7503 DK-725 -
6310 B-7714 DK-7714 -
636 B-7504 DK-724 CH-712
638 B-7504 DK-724 CH-712
8200 series B-7714 DK-7714 -
8300 B-7714 DK-7714 -
8390 B-7714 DK-7714 -
8890 B-7714 DK-7714 -
918 B-7578, B-778 - CH-713

Cell Phone Batteries & Accessories

21

Cell Phone Batteries & Accessories

Nokia (cont.)

Ringo B-7504 DK-724 CH-712

Panasonic

EB-H63 B-7620 - -
EB-TX210 (Blue) B-7544 DK-7544 -

Philips

PR-747 B-7574, B-774 DK-723 CH-721

Pioneer

PCC1500 B-755, B-783 DK-713 CH-717
PCC700 B-755, B-783 DK-713 CH-717
PCC720 B-755, B-783 DK-713 CH-717
SELECT 6000 B-755, B-783 DK-713 CH-717

Qualcomm

1960 B-7591 DK-7591 -
2760 B-7591 DK-7591 -
2760 Thin Phone B-7591 DK-7591 -
860 B-7591 DK-7591 -
CDM1960 B-7591 DK-7591 -
CDM860 B-7591 DK-7591 -
Q B-7598 DK-738 -
QCP-1900 B-7596 DK-736 -
QCP-1960 B-7591 DK-7591 -
QCP-2700 B-7597 DK-737 -
QCP-2760 B-7591 DK-7591 -
QCP-800 B-7596 DK-737 -
QCP-820 B-7597 - -
QCP-860 B-7591 DK-7591 -
Touchpoint (New) B-7628 - -

Samsung

2000 B-7624 DK-733 -
N200 B-7549 - -
SC-H3500 B-7508 DK-733 CH-723
SCH-1900 B-7711, B-7713 - -
SCH-200 B-7536 - -

Samsung (cont.)

SCH-2000 B-7501 - -
SCH-210 B-7711, B-7713 - -
SCH-211 B-7711, B-7713 - -
SCH-220 B-7536 - -
SCH-250 B-7536 - -
SCH-2530 B-7608, B-7609 DK-733 CH-723
SCH-3500 B-7508 DK-733 CH-723
SCH-400 B-7608, B-7609 DK-733 CH-723
SCH-411 B-7608, B-7609 DK-733 CH-723
SCH-670 B-7508 DK-733 CH-723
SCH-800 B-7536 - -
SCH-810 B-7554, B-7556 - -
SCH-811 B-7554, B-7556 - -
SCH-811i B-7548, B-7553 DK-733 -
SCH-850 B-7548, B-7553 DK-733 -
SCH-8500 B-7548, B-7553 DK-733 -
SCH-8500SIL B-7548, B-7553 DK-733 -
SCH-870 B-7536 - -
SGH-600 B-7536 - -
SPH-A460 B-7650 DK-7650 -
SPH-N200 B-7549 - -
Voicer 411 B-7608, B-7609 DK-733 CH-723
Voicer 811 B-7554, B-7556 - -

Sanyo

SCP-350 B-7637 - -
SCP-4000 B-7637 - -
SCP-4500 B-7637 - -
SCP-4700 B-7637 - -

Siemens

C25 B-7540 - -
S3 B-7537, B-7538 - -
S3 COM B-7537, B-7538 - -
S3+ B-7537, B-7538 - -

S4 B-7596 DK-737 -
S6 B-7539 - -
S6is B-7539 - -

Sony

100 B-7600 DK-735 -

Cell Phone Batteries & Accessories

Cell Phone Batteries & Accessories

22

Sony (cont.)

1920 B-7597 DK-736 -
600 B-7596 DK-736 -
777 B-7604 - -
820 B-7597 DK-736 -
888 B-7604 - -
CDX1000 B-7596 DK-737 -
CM-H777 B-7604 - -
CM-H888 B-7604 - -
CMRX 100 B-7600 DK-735 -
S3 B-7537, B-7538 - -
S3+ B-7537, B-7538 - -

Sony Ericsson

T68 B-7647 - -
T68i (Grey) B-7647 - -
T68i (Silver) B-7648 - -

Sprint

Dual B-7508 DK-733 CH-723
QCP 2700 B-7597 DK-737 -
Qualcomm 1960 B-7591 DK-7591 -
SCH-8500 B-7548, B-7553 DK-733 -
TouchPoint B-7628 - -
TouchPoint 2100 B-7552 DK-7552 -
TouchPoint 2110 B-7552 DK-7552 -
TouchPoint 2200 B-7552 DK-7552 -

Technophone

400 B-7563 - CH-719
405 B-7566 DK-723 CH-720
415 B-7566 DK-723 CH-720
515 B-7570, B-7571 DK-723 CH-722
EZ400 B-7563 - CH-719
EZ405 B-7566 DK-723 CH-720
EZ415 B-7566 DK-723 CH-720
PC-515 B-7570, B-7571 DK-723 CH-722
PC515 B-7570, B-7571 DK-723 CH-722
TD815 B-7574, B-774 DK-723 CH-721

Verizon

LG-510 (Black) B-7642 DK-7630 -
LG-510 (Silver) B-7630 DK-7630 -
V111 B-7693 - -

Cordless Phone Batteries

23

Cordless Phone Batteries

AT&T

1000 series B-702

3000 B-702
3095 B-726
3400 B-702
3410 B-702
4000 series B-702
5000 series B-702
59768 B-709
7000 series B-702
9050 B-725
9100 B-709
9112 B-742
9115 B-742
9120 B-709
9150 B-742
9301 B-737
9320 B-737
9340 B-737
9350 B-737
9355 B-737
9370 B-737
9400 B-758
9450 B-758
9555 B-742
HT series B-702
MCL5 B-702
Nomad 200 B-705
Nomad 3000 B-702
Nomad 400 B-705
Nomad 4000 B-702
Nomad 4000A B-702
Nomad 4200 B-702
Nomad 4210 B-702
Nomad 4400 B-715
Nomad 450 B-712
Nomad 5200 B-702
Nomad 5300 B-702
Nomad 750 B-705

Audiovox

A12 B-705
A15 B-705
AT20 B-705
DST961 B-726

Bell South

32001 B-700
32011 B-700
3582 B-703
3675 B-703
3893 B-703
584 B-703
639 B-703
667 B-703
674 B-703
684 B-703
687 B-703
699 B-703
702 B-703
798 B-703
820 B-703
HAC535 B-703
HAC629 B-703
HAC664 B-703
HAC673X B-703
HAC677 B-703
HAC688 B-703
HAC699 B-703
HAC711 B-703
HAC863 B-703
MH9011 B-747

Casio

Phone Mate B-762

Cidco

CL-980 B-739

CL-990 B-739

Cobra

AN8525 B-700

AN8630LS B-700

CP115SA B-747

CP130SA B-747

CP2506 B-700

CP2510 B-700

CP302S B-747

Cobra (cont.)

CP320 B-705

CP443S B-747

CP460 B-700

CP471S B-700

CP486 B-700

CP492 B-700

CP702 B-700

CP706 B-700

CP714 B-700

CSPA B-705

GE

2-26993GE1 B-768

2-3645 B-702

2-6700 B-700

2-6700GE1-A B-702

2-6730 B-702

2-6790 B-702

2-6920A B-737

2-6921A B-747

2-6922GE1 B-737

2-6922GE2 B-737

2-6928GE1 B-737

2-6930GE1 B-768

2-6932 B-700

2-6936GE2-A B-747

2-6938GE1 B-737

2-6938GE2 B-737

2-6970GE2 B-702

2-6975GE2 B-747

2-6980GE1 B-768

2-6985GE1 B-768

2-6990 B-737

2-6990GE1-A B-762

2-6993 B-737

2-6994 B-737

2-7700GE2-M B-747

2-7730GE2-A B-747

2-7910GE1 B-768

2-7920GE3 B-768

2-7920GE4 B-768

2-7930GE3 B-768

2-7935GE3 B-768

2-7939GE3 B-768

Cordless Phone Batteries

Cordless Phone Batteries

GE (cont.)

2-7990GE3 B-768
2-7993 B-768
2-911SST B-735
2-912SST B-735
2-913SST B-735
2-920SST B-735
2-9368 B-702
2-9414 B-700
2-9510 B-700
2-9512 B-700
2-9514 B-700
2-9515 B-700
2-9519A B-700
2-9522 B-700
2-9525A B-700
2-9582 B-700
2-9625 B-700
2-9626 B-700
2-9630A B-700
2-9631 B-700
2-9635 B-702
2-9645 B-702
2-9682 B-702
2-9738 B-702
2-9750 B-702
2-9755 B-702
2-9775 B-702
2-9785 B-702
2-9825 B-702
2-9921C B-747
2-9930 B-747
5-2108 B-701
5-2298E B-700
5-2301 B-700
5-2304 B-700
5-2308 B-700
5-2309 B-700
5-2310 B-700
5-3304 B-700

IBM

3455 B-762

Magnavox

CDT900PC B-702
CLT254PC B-702
CLT264PC B-702
CTL354PC B-702

Microsoft

M-900 B-756
MP-900 B-756

Northern Telecom

3210C B-700
Nomad 6300 B-700
Nomad 6500 B-700

Northwest Bell

32001 B-705
32529 B-733
EX3000 B-705
Excursion B-700
Excursion 3210 B-700
Excursion 36247 B-747
Excursion 39210 B-747

Excursion 3300 B-705
Excursion 32529 B-733

Pacific Bell

2282504 B-702
800 B-702
810 B-702
820 B-702
840 B-702
CL980 B-739
CS-8100 B-702
CS-8200 B-702
CS-8410 B-702
CP320SA B-705

Panasonic

KX-3815 B-705
KX-3908 B-701
KX-A92 B-719
KX-T210 B-752
KX-T3600 series B-701
KX-T3800 B-701
KX-T3807 B-701
KX-T3832 B-701
KX-T3845 B-705
KX-T3850 B-701
KX-T3860 B-701
KX-T3875 B-701
KX-T3900 B-705
KX-T3912 B-701
KX-T3920 B-701
KX-T3932 B-701
KX-T3945 B-701
KX-T3960 B-701
KX-T3967 B-701
KX-T3980 B-701
KX-T4168 B-701
KX-T4300 B-701
KX-T4342 B-701
KX-T4370 B-701
KX-T4500 B-701
KX-T8832 B-705
KX-T9500 B-710
KX-TC100 B-701
KX-TC100W B-701
KX-TC155 B-701
KX-TC180 B-701
KX-TC180B B-701
KX-TC1866B B-752
KX-TC1868B B-728
KX-TCM939 B-705
KX-TG1743 B-728
KX-TG200 B-752
KX-TG2000 B-730
KX-TG2396B B-744
KX-TG240 B-752
KX-TG2400B B-744
KX-TG2500B B-744
KX-TG2503 B-728
KX-TG2550S B-744
KX-TG2560 B-744
KX-TG2570 B-744

Cordless Phone Batteries

25

Cordless Phone Batteries

Panasonic

KX-TG2650 B-751
KX-TG2670N B-751
KX-TG2679N B-751
KX-TG4000 B-730
KX-TGA200 B-730
KX-TGA400 B-730

Phone Mate

2000 series B-702
CP725 B-702
TC520 B-702
TC540 B-702

Sanyo

CLT156 B-700
CLT170 B-700
CLT176 B-700
CLT300 B-700
CLT3300 B-700
CLT33001 B-700
CLT3300A B-700
CLT3301A B-700
CLT3600 B-700
CLT4300 B-700
CLT5400 B-700
CLT5600 B-700
CLT580 B-700
CLT6300 B-700
CLT667 B-700
CLT760 B-700
CLT8801 B-700
CLT927 B-747
CLT937 B-747
CLT947 B-747

Sharp

C2651 B-703
CL150 B-703
CL155 B-703
CL255 B-703
CL350 B-703

Sharp (cont.)

CL410 B-728
CL510 B-703
CL555 B-703
FT4160 B-703
FT4260 B-703
FT4355 B-703
FT5400 B-705
FT5510 B-703
SR2000 B-703

Sony

SCT-100 B-706
SPP-1000 B-706
SPP-1010 B-706
SPP-115 B-706
SPP-11H B-706
SPP-120 B-706
SPP-130 B-706
SPP-160 B-706
SPP-170 B-706
SPP-190 B-706
SPP-200 B-706
SPP-2000 B-706
SPP-200C B-706

SPP-2010 B-706
SPP-205 B-701
SPP-206 B-701
SPP-2100 B-706
SPP-3000 B-706
SPP-4000 B-706
SPP-5100 B-706
SPP-57 B-701
SPP-71 B-701
SPP-72 B-701
SPP-75 B-706
SPP-85 B-706
SPP-8500 B-706
SPP-8700 B-706
SPP-900 B-726
SPP-910 B-726
SPP-920 B-726
SPP-930 B-726
SPP-933 B-728
SPP-935 B-726

Sony (cont.)

SPP-97 B-706
SPP-A250 B-701
SPP-A450 B-701
SPP-A900 B-728
SPP-A946 B-728
SPP-A957 B-752
SPP-A967 B-752
SPP-A968 B-752
SPP-AQ150 B-701
SPP-AQ55 B-701
SPP-AQ65 B-701
SPP-AQ71 B-701
SPP-AQ73 B-701
SPP-D900 B-728
SPP-ID400 B-701
SPP-M100 B-706
SPP-M920 B-726
SPP-M937 B-726
SPP-N1001 B-732
SPP-N1003 B-732
SPP-N1004 B-732
SPP-Q100 B-706
SPP-Q150 B-701
SPP-Q300 B-706
SPP-S9000 B-760
SPP-S9001 B-760
SPP-S9101 B-760
SPP-S9104 B-760
SPP-SS951 B-752
SPP-SS960 B-728
SPP-SS961 B-752
SPP-SS966 B-752
SPP-V72C B-701
SPP-X50 B-706
TBPT40 B-706

Southwestern Bell

2-9931A B-739
EX1960 B-705
EX905 B-705
FF1150 B-705
FF1185 B-704
FF1710 B-704
FF1720 B-704

Cordless Phone Batteries

Cordless Phone Batteries

26

Southwestern Bell (cont.)

FF1741 B-704
FF1765 B-704
FF650 B-705
FF664 B-704
FF670B B-704
FF692 B-704
FF714 B-704
FF740 B-705
FF8066 B-705
FF950 B-728
FF980 B-739

Toshiba

FT-2500 B-701
FT-3005 B-701
FT-5005 B-753
FT-6000 series B-701
FT-7000 series B-701
FT-8006A B-728
FT-8507 B-728
FT-8509 B-728
FT-8809 B-728
FT-8900 B-728
FT-8905 B-728
FT-8906 B-728
FT-9000 series B-701
SG-1801 B-752

Uniden

B3801 B-705
DX3555 B-701
DX3565 B-701
DX419 B-701
DX4534 B-701
DX719 B-701
DX1860 B-701
EX17960A B-728
EX255 B-705
EX3300 B-705
EX4100 B-705
EX4112 B-705
EX945 B-705

Uniden (cont.)

EXA915 B-728
EXAI7980 B-728
EXAI918 B-728
EXL-8900 B-728
EXL-8901 B-728
EXLI8962 B-728
EXP7900 B-728
EXP7904 B-728
EXP91 B-728
EXP92 B-728
EXS9910 B-731
EXS9950 B-731
EXS9960 B-731
EXS9995 B-731
QVA4505 B-701
XC302 B-701
XC314 B-701
XC345 B-701

XC3530 B-701
XC610 B-701
XC714 B-701
XCA2500 B-701
XCA4510 B-701
XCI660 B-701

V-Tech

900DL B-709
900DX B-709
910ADL B-736
912ADL B-736
914ADJ B-726
914ADL B-736
916ADL B-736
917ADL B-736
917ADX B-725
918ADL B-736
921ADL B-736
VT1711 B-726
VT1718 B-726
VT1721 B-726
VT1733 B-726
VT1900 B-736
VT1901 B-726
VT1901C B-725

V-Tech (cont.)

VT1910 B-736
VT1920 B-736
VT1922 B-726
VT1923 B-726
VT1930 B-736
VT1930C B-736
VT1932 B-726
VT1940 B-736
VT1970 B-736
VT2420 B-741
VT2421 B-741
VT2428 B-737
VT2431 B-741
VT2460 B-741
VT2461 B-741
VT2900 B-736
VT2910 B-736
VT2920 B-736
VT2920C B-725
VT9000 B-736
VT9060 B-736
VT9105 B-726
VT9108 B-726
VT9111 B-726
VT9112 B-726
VT9115 B-726
VT9117 B-737
VT9121 B-726
VT9122 B-737
VT9141 B-726
VT9151 B-726
VT9155 B-726